


Leopard. I



LEOPARD Tractor



- Front Bumper # 500821
- 2x Bolts # 500351
- 2x Nuts # 750127

Model 501400 = 14 hp Series I.

Takes Cox electric clutch 232201.

... data washer. Tighten to SS boards with loctite.

09 410 6381

6000000

LEOPARD PARTS LIST - SERIES I & II (Continued)

LEOPARD PARTS LIST - SERIES I & II

REF NO.	PART NO.	DESCRIPTION	REF NO.	PART NO.	DESCRIPTION
1	750768	Seat	50	500144	Gauge - Ammeter
2	500169	Plate - Seat	51	750341	Battery
3	750770	Spring - Compression Seat	52	500141	Bush - S13
4	500171	Mounting - Seat R/H	53	500266	Collar
5	500170	Mounting - Seat L/H	54	500043	Shaft Assy - Steering (Series I)
6	751170	Spacer - Seat		500423	Shaft Assy - Steering (Series II)
7	500210	Cowl - Seat	55	750219	Nipple - Grease
8	751917	Tank - Fuel ⁴⁹³¹⁸³ 751178 CAP. FUEL	56	500069	Steering Box Assy (Series I)
9	500161	Plunger Assy - Lift Lever		500457	Steering Box Assy (Series II)
10	500197	Grip - Lift Lever	57	500195	Spacer - Steering Box
11	500157	Lever - Lift	58	500297	Quadrant - Steering + Bush at
12	500162	Pin - Lift Lever	59	500216	Control Assy - Throttle Bottom
13	750180	Pin - Roll	60	500168	Pedestal Assy
14	500200	Spacer - Lift Quadrant ⁵⁰⁰¹⁸¹	61	500263	Trim - Pedestal (Bottom) ^{is 500150}
15	500199	Quadrant - Lift		500206	Trim - Pedestal (Top)
16	500154	Plate - Wear	62	500424	Console Assy
17	750405	Key - Woodruff	63	500084	Pedal Assy - Clutch
18	750351	Transaxle 801-030 ^{CHANGED TO}	64	750272	Solenoid
19	500054	Arm - Selector ^{MST AUG 97}	65	500001	Chassis
20	500118	Spacer - Hub ⁵⁰⁵²⁴²	66	500156	Stop Assy - Bonnet (Series I)
21	752078	Hub - Rear Wheel ^{TMS -MST}	67	500373	Stop Assy - Bonnet (Series II)
22	750300	Tyre - 18 x 950 x 8	68	500048	Plate Assy - Bonnet
23	750300 MG	Tyre - Mudgrip 18 x 950 x 8	69	500080	A Frame - Bonnet (Series I)
24	500138	Rim		500435	Hinge - Bonnet (Series II)
25	750613	Key - Rear Wheel	70	500208	Bonnet Assy (Series I)
26	750193	Circlip		500430	Bonnet Assy (Series II)
27	750499	Cap - Hub	71	500201	Reflector - Rear Head Light
28	500172	Link - Gear Lever		500202	Reflector Assy - Centre
29	750347	Ball Joint - 10mm (Series I)		500203	Lens - Headlight (Series I)
30	500300	Ball Joint - 12mm (Series II)		500204	Trim - Lens (Series I)
31	500265	Spring - Brake Rod		500432	Lens - Headlight L/H (Series II)
32	500411	Bracket Assy - Brake Rod		500431	Lens - Headlight R/H (Series II)
33	500056	Rod - Brake	72	500437	Trim - Lens (Series II)
34	750383	Spring - Pan Return		500147	Bulb Holder
35	850117	Pulley - Idler ^{18" Now}	73	500145	Bulb - LLB382
36	500174	Spacer - Clutch Idler ²³²²⁰¹	74	750305	Engine - B&S
37	750387	Spring - Clutch Arm Return ^{20" 502107}		500177	Pulley - Engine (Manual)
38	500089	Arm Assy - Clutch		500448	Pulley - Engine (Hydro) ^{now STEEL 36-1}
39	500057	Rod - Clutch ^{ASK SERIES I OR II}	75	750371	Clutch/Brake Ogura ^{NOT ALLOY}
40	500304	Pulley - Clutch	76	750609	Washer - Engine ^{see e. clutch notes.}
41	500183	V Belt - A88 ^{(Manual) 500454 - A81 (MST)}	77	500120	Link - Drag (Series I) ^{→ OBSOLETE}
42	500085	Pedal Assy - Brake		500301	Link - Drag (Series II) ^{SEE NOTES}
43	500136	Arm Assy - Stabiliser	78	500094	Arm Assy - Steering
44	500151	Adjuster - Pan	79	750103	Screw - Grub
45	750200	Pin - Steering Wheel	80	500141	Bush - S13A
46	750766	Steering Wheel	81	750219	Nipple - Grease
47	500148	Switch P403	82	500235	Axle - Stub Assy L/H
48	750280	Switch - Ignition ^{750273 KEY}	83	500244	Bolt - M16 x 75
49	500146	Lamp - Warning + BULBS (21/193)	84	500045	Beam - Assy Axle
	500182	Bulb - Warning Lamp LLB987	85	751631	Tie Rod
	500061	Fuse Holder	86	500266	Collar
			87	500299	Axle - Stub Assy R/H
			88	500141	Bush - S13A (Series I)
				500321	Bush - S13 (Series II)
			89	850121	Washer - Flat
			90	750128	Nut - Nyloc M16
			91	750397	Cap - Plastic
			92	750295	Tyre - 15/600
			93	750296	Tube - 15/600

09 235 0532

520 Long
466 long

465-401-

(see note PTO)

Kingpin.

Muffler
500253.

Blade engage - Dash
500148.

LEOPARD PARTS LIST - SERIES I & II (Continued)

REF PART DESCRIPTION
NO. NO.

PARTS NOT ILLUSTRATED

500393 Nut - Wheel (Rear)

500114 Pipe - Oil Drain

751186 Plug - Oil Drain

750237 Knob - Gear Lever

750769 Microswitch

750273 Key - Ignition

750432 Key - Engine Pulley

750336 Bearing - Clutch Pulley

~~500475~~ Decal - Bonnet (Set) *still same in stock of JCM*

~~500476~~ Decal - Guard (Set) *500484*

500477 Decal - Cutting Height

500250 Decal - Dash

500207 Trim - Bonnet

500264 Buffer - Seat

500217 Pulley - Input Transaxle

500173 Bracket - Electric Clutch

500058 Guide - Belt (Series I & II)

500182 Bulb - Warning Lamp LLB987

500145 Bulb - LLB382

500214 Rim - 6" Front

~~751918~~ Cap - Fuel

500319 Wheel - Centre RWX150

* ~~500061A~~ Wire - Fuse

500469 Stiffener - Rear Cowl

~~500059A~~ Loom (Series I) *obsolete* *new: 500059C + 500061A*

500059C Loom (Series II)

~~500059B~~ Loom - Extension (Series I) *obsolete*

500059D Loom - Extension (Series II)

500060 Wire - Light

~~500061~~ Wire - Fuse (Series I) *obsolete*

* 500061A Wire - Fuse (Series II)

500063 Lead - Negative Earth

500064 Lead - Positive Short

500065 Lead - Positive Long

500467 DECAL - CAT KINGCAT

500452 DECAL - 16HP SERIES II

500428 DECAL - LEOPARD SERIES II

502322 SPRING - LIFT LEVER

500181 SPACER - LIFT LEVER

LYNX: - LEVER ASSY - HANDBRAKE COMPLETE

- 1 x 502242 LEVER ASSY - HANDBRAKE
- 1 x 750237 KNOB
- 1 x 750102 NUT - NYLOC M8
- 1 x 750203 WASHER - STARLOC 1/4

502224
DECAL - BONNET FRONT

502223
DECAL - BONNET RH SIDE

502272
DECAL - BONNET LH SIDE

493988

500475

still same in stock of JCM

500484

obsolete now 500059C + 500061A

